

# ILLUSTRATED MEMBRANE INSTALLATION

National Applied Construction Products, Inc. • 800.633.4622 • Fax: 330.644.3557 • www.NACproducts.com

**IMPORTANT:** This is not a stand alone document and does not include complete crack isolation, waterproofing or sound abatement instructions. Refer to ECB, Strataflex, SAM<sup>3</sup> and Super SAM Install Sheets for complete instructions.

**1**

- Begin with a clean, dry floor.
- Apply 101 Floor Prep if needed. Allow 24 hours to cure.

**2**

- Measure and pre-cut membrane 4-6" longer than required.
- Butt joint **ECB, SAM<sup>3</sup> or Super SAM** side seams. Overlap **Strataflex** side seams at 2" double-stick edge.
- Re-roll membrane to half the room's depth.

**3**

- Apply Primer to substrate. Prime only an area that will be covered by membrane within four hours.

**4**

- Slit release paper. Membrane will roll out across primed floor.

**5**

- Press membrane into place with flat side of trowel or 75-100# roller. Pay extra attention to Strataflex side seams.



**BUTT JOINT:** ECB, SAM<sup>3</sup> or Super SAM side seams and ECB, Strataflex, SAM<sup>3</sup> or Super SAM end seams.



**OVERLAP:** Strataflex side seams. Remove film from 2" double-stick edge on underlying sheet and carefully press into place.

