INSTALL Seam Tape and Preformed Inside/Outside Corners

National Applied Construction Products, Inc. • 800.633.4622 • Fax: 330.644.3557 • www.NACproducts.com

IMPORTANT: These products are for use with sheet or liquid applied membranes for waterproofing applications. Read and understand Product Data (PDS) and Material Safety Data (MSDS) Sheets for all products prior to installation.

Install 6" Seam Tape

- Apply NAC TAC Interior Primer or NS97 Exterior Primer to area where Tape will be affixed.
- Cut Tape to desired length and remove white release paper.

END SEAMS *(36" Wide start and end terminus of Membrane Sheet)*	• Place Tape perpendicular to 36" End Seam so Membrane will overlap Tape by 3". • Allow first Membrane Sheet to overlap Tape by 3". Start second Membrane Sheet over remaining 3" of Tape. Do not overlap Membrane Sheets. Remove protective film from top of Tape. See final instructions at bottom of page.
FLOOR-TO-WALL, WALL-TO-WALL AND WALL-TO-CEILING JOINTS	• Place Seam & Corner Tape so that equal amounts of Tape are applied to adjacent surfaces. For example, for a Floor-to-Wall Joint application, apply 3" of Tape to floor and 3" of Tape to wall. • Align one Membrane Sheet to overlap Tape on floor and one membrane sheet to overlap Tape on wall. Remove protective film from top of Tape. See final instructions at bottom of page.
PROTRUSIONS, DRAINS, SHOWER CURBS, NICHES AND SEATS	• Use Tape to best advantage to form a watertight seal. • Remove protective film from top of Tape. See final instructions at bottom of page.
SIDE SEAMS *(50' edge seams)*	*For waterproofing Membrane Systems at edge seams. NOT REQUIRED at the Strataflex overlap edge.* • Place Tape approximately 3" from starting edge of Membrane sheet. • Allow first Membrane Sheet to overlap Tape by 3". Start second Membrane Sheet over remaining 3" of Tape. Do not overlap Membrane Sheets. Remove protective film from top of Tape. See final instructions at bottom of page.

Install PFI (Inside) / PFO (Outside) Corners

FOR STRATAFLEX AND OTHER SHEET APPLIED MEMBRANE APPLICATIONS:

1) Apply NAC TAC or NS97 Primer to the inner face of the Corner and substrate.
2) Press Corner into place with hand, then flatten with putty knife or flat trowel. Take special care to avoid cutting or damaging corner.
3) Apply liberal coat of Primer to outer face of Corner.
4) Proceed with installation in accordance with Membrane's Install sheet.

FOR STRATASEAL/SUBSEAL AND OTHER LIQUID MEMBRANE APPLICATIONS:

1) Apply Membrane to inner face of Corner and substrate.
2) Press Corner into place with hand, then flatten with putty knife or flat trowel. Take special care to avoid cutting or damaging corner.
3) Apply liberal coat of Membrane to outer face of Corner.
4) Proceed with installation in accordance with Membrane's Install sheet.

ADDITIONAL INSTRUCTIONS FOR 6" SEAM TAPE APPLICATIONS:

- This product is for use with Sheet Applied and/or Liquid Applied Membrane installations. Read and understand all Product Data (PDS) Install Sheets, Install Sheets and Packaging for additional guidelines.
- StrataSeal/SubSeal Liquid Waterproofing Membrane is ideal for use in hard to reach areas.
- For Sheet-Applied Membrane installations, allow underside of self-adhesive Membrane come in contact with top of Tape.
- Use 75-100# Roller or Flat Side of Trowel to press Membrane into place. Check bond at seams.
- Seal cut or perimeter edges with StrataSeal/SubSeal or other approved sealant.
- If water test is required, allow 48 hours to cure, otherwise tile can be set immediately.

NOTES:_____

© NAC Products, Inc. • All Rights Reserved

Products and specifications subject to change without notice. Refer to current TCA Handbook for additional guidelines.